



# B61001

## User manual



Please read this manual before using the product to fully understand its use and operation.

## CAUTION

- The company reserves the right to modify the contents of this manual without any further notification. Some functions may vary in certain versions of software.
- Please charge this product with the charger provided for no less than 2 hours before using it for the first time. Use only the charger that is included with the product. Make sure that the charger and the smart watch are properly connected while charging. Do not charge if the watch has water (or sweat) to avoid short circuits and damaging the product.
- Avoid hitting the smart watch, it could break the glass.
- The waterproof rank is IP68, therefore the smart watch can be used for daily life. But the smart watch cannot be used for diving or be under water for a long time. Furthermore, the smart watch cannot be used in showers / baths with hot water (the water steam can damage it) or in salt water (if it entered the smart watch, it would corrode the internal parts).

### **System Requirements:**

Android: Android 5.0 or above

iPhone: iOS 9.0 or above

## Download and install the application

1. Go to our website [www.mareasmart.com](http://www.mareasmart.com) and find your smart watch model. The model number is found on the

back of the smart watch (it starts with “B” and is followed by five digits).

2. Download and install on your phone the official app that corresponds with your smart watch model.
3. Open the app and enable all the permissions that the app requests.
4. Turn on Bluetooth on your phone.
5. Make sure that the smart watch has not been linked directly through Bluetooth to your phone. If so, unlink it.
6. Bind your Marea Smart watch through the app.

### **Notes on linking:**

- Only one smart watch pairing application should be installed on the phone to ensure that the connection with the smart watch is normal. If several applications are connected, they can affect the connection between the watch and the phone. Some Android phones will prompt you that they cannot install the app. Please go to ‘settings’ of the phone and authorize the ‘Unknown source’.
- When the mobile phone requests permissions, click "Allow". On the contrary, you may not receive notifications, scan QR codes, open the remote camera or use other functions. These permissions do not affect the flow of the phone or other information on the phone.
- Some Android phones may accidentally close the app when cleaning the applications. Please keep the app running in the background. To turn on this function on

your phone: open the phone settings - application management - official application - rights management - backstage management - select background running. The setting method may be different due to different mobile phone versions and models.

- For iPhone: if the phone is in standby or hibernation mode for a long time (for example, the phone has not been in use for 2 hours or more and the screen is off), the application will be closed by the iOS system, so the application and the watch will be disconnected and the application functions will not be available. Re-activate the phone and it will automatically reconnect.

## Smart watch operation



### Turn on/off

Press and hold the side button for 3 seconds to turn on the smart watch; short press the side button to activate the watch when in standbymode.

Press and hold the side button for 3 seconds to turn off the smart watch.

## **Button and screen operation**

From the home screen on the smart watch:

- Swipe down to see the status bar. It shows the connection status and battery, and includes quick access to some functions (do not disturb mode, settings, find phone, info about smart watch, and brightness control).
- Swipe up to enter the messages interface.
- Swipe right to enter the main menu.
- Swipe left to enter the shortcut menu. It includes steps, distance and calories, heart rate monitor, sleep monitor, and weather.

## **Return**

From any function, swipe right or short press the side button to return to the main menu.

From the main menu, swipe left or short press the side button to return to the home screen.


## **Home screen selection**

Long press the home screen to enter the selection interface, swipe right /left to see all available options. Click on the desired screen to make it your home screen.

On the app you can download other predesigned home screens as well as select an image saved on the phone to set as your home screen.

## Main functions in Smart watch

The main menu includes the following functions:




### Data

Shows the steps taken, the distance traveled and the calories consumed on the current day. You can check the historical data on the app.



### Motion

Includes different sport modes: walking, running, biking, climbing, swimming, yoga, elliptical machine, basketball, football, ping pong and badminton. On the last icon and on the app you can check the historical data.



### Messages

Shows the last 8 messages / notifications. The phone and the watch must be linked and within the Bluetooth range.

Notifications cannot be deleted. The last notification received will replace the oldest one. On the app you can select what type of notifications you want to receive on the smart watch.



### **Heart Rate**

Upon entering the function, the heart rate measurement will start automatically. Wait about 1 minute for the measurement to finish. The data will be displayed in more detail on the app.



### **Blood Pressure**

Upon entering the function, the blood pressure measurement will start automatically. Wait about 1 minute for the measurement to finish. The data will be displayed in more detail on the app.




### **Blood Oxygen**

Upon entering the function, the blood oxygen measurement will start automatically. Wait about 1 minute for the measurement to finish.

### **Notes on health functions:**

- The heart rate, blood pressure, and blood oxygen functions require the watch and arm to be in contact, and the watch should not be too tight or too loose. The test can be inaccurate if it is too tight because it will affect blood flow, and if it is too loose because it will affect the monitoring of the heart rate sensor.

- The results of the smart watch measurements are only indicative and cannot substitute in any case for any medical test. Please follow your doctor's instructions and do not rely solely on these results for an evaluation.



### **Sleep Monitor**

If you have worn the watch during the previous night, it shows the total sleep time of last night, as well as light and deep sleep times. You can check the historical data on the app.



### **Music remote control**

Displays buttons to play / pause and skip to previous or next song, to remotely control the music playing on the paired phone.




### **Weather**

Displays the current weather and temperature. The phone and the watch must be linked so the watch can receive the weather info from the phone.




### **Alarm clock**

Displays the alarms that are activated. The alarms are set and activated on the app.



### **Stopwatch**

Click on the start icon to start the count. When the time is paused, click the reset icon to reset to 0.



### **Timer**

Select one of the preset times or click “+” to select your own time. Click on the start icon to start the countdown. When the countdown is paused, click the reset icon to reset to the original time.

### **Find phone**

The paired phone will ring so you can find it. The phone and the watch must be linked and within the Bluetooth range.

## **Settings:**

### **QR code**

Scan the QR code with your phone to download the app through your app store or browser.

## System:



### Shut down

Turns off the smart watch (click on "√" to confirm or "×" to exit).



### Restore Factory

Resets the smart watch to factory settings (click "√" to confirm or "×" to exit). This function will erase all the data saved on the smart watch.



### About

Displays the Bluetooth name, Mac address and version number.

## Display:



### Dial Setting

Swipe right / left to see all available options. Click on the desired screen to make it your home screen.

On the app you can download other predesigned home screens as well as select an image saved on the phone to set as your home screen.



## **Brightness Control**

Click "+" to increase and click "-" to decrease the brightness of the screen. The brighter it shines, the more battery it will use.

**Main functions on the app** (they can only be used if the smart watch is linked)

## **Notifications**

Activate notifications for each of the apps you want to receive notifications from on your watch. When the phone receives incoming calls or new notifications from the activated apps, these notifications are received on the smart watch as well. The last 8 messages / notifications can be viewed in the message interface on the smart watch.

## **Dial Setting**

It includes a wide gallery of home screens that can be downloaded to the smart watch, as well as the possibility of customizing your own home screen using an image saved on the phone (or taking a photo with the phone's camera) and selecting the font color.

## **Sedentary reminder**

If this function is activated, when you have been in the same position for a long time, the watch will vibrate and display the corresponding icon to remind you to get up and move.

## **Alarm clock**

It is set on the app and, when the selected time arrives, the watch will vibrate and display the corresponding icon. You can set up to 3 alarms.

## **Do not disturb mode**

You can set a time interval in which the smart watch will not receive notifications and / or its screen will not turn on when you lift your wrist.

## **Raise wrist to turn on screen**

If this function is activated, the smart watch screen will turn on when you lift your wrist.

## **Camera remote control**

The camera on the phone will open. Shake the smart watch and the phone will take a photo. The photo will be saved in the phone's gallery.

Note: When the camera usage request appears, select "Allow".

## **Find smart watch**

The smart watch will vibrate so you can find it. The phone and the watch must be linked and within the Bluetooth range.

## **Firmware update**

If there is a new version of the smart watch's firmware, it will update to the latest version.

## **Unlink**

Click to unpair the smart watch from the paired mobile phone.